

SKIN | MUST-HAVE LOTION | W/O COLD CREAM | SC-FAC-030-05 | PUMP DISPENSER

Phase	Tradename	INCI (EU)	Supplier	%
A	Hydriol PGI	Polyglyceryl-4 Isostearate	Hydrior	1.00
	Dermofeel PGPR	Polyglyceryl-3 Polyricinoleate	Evonik Dr. Stra- etmans	2.00
	Isopropyl Myristate	Isopropyl Myristate	BASF	6.00
	Miglyol DO	Decyl Oleate	IOI Oleo	9.30
	KahlResin 1218 Eco	Hydrogenated Styrene/Methyl Styrene/ Indene Copolymer, Paraffinum Liquidum	Kahl	3.00
	KahlWax 2811 Rice	Oryza Sativa Bran Cera	Kahl	1.25
	Magnesium Stearate	Magnesium Stearate	--	0.50
Tocopherol	Tocopherol	--	0.05	
B	Water	Aqua	--	ad 100
	Magnesium Sulfate X 7H2O	Magnesium Sulfate	--	1.00
	Glycerin	Glycerin	Merck	4.00
C	Curl Contour Hydra Cell KVON Preservative	Parfum	Düllberg	0.30 q.s.

Thanks to its high water content, this face cream delivers cooling hydration and comfort to dry and sensitive skin. The rich formula also builds a protective layer against cold, dry air, and wind, which protects the skin from moisture loss, keeping it plump and supple.

Procedure

Heat phase A to 105 °C, stir until everything is melted, then cool to 85 °C. Heat phase B to 85 °C. Add phase B slowly in small portions to phase A and continue mixing. Homogenize for 30 seconds at 70 °C and cool to 45 °C. Add phase C and cool further to 30 °C. Fill into suitable packaging.

